


- 162 306 000 Fusible/fuse - 5 A (x 6)
- 162 308 000 Fusible/fuse - 10 A (x 9)
- 162 309 000 Fusible/fuse - 15 A (x 4)
- 162 310 000 Fusible/fuse - 20 A (x 5)
- 162 311 000 Fusible/fuse - 25 A (x 1)
- 162 312 000 Fusible/fuse - 30 A (x 4)

- R1 Indicator Central
- R2 Starting
- R3 Oil and water level
- R4 Oil buzzer
- R5 Handbrake buzzer
- R6 Lighting
- R7 Cab headlights
- R8 Bottom tank pump
- R9 Reverse light
- R10 After starting
- R11 Spraying pump cut
- R12 High suspension
- R13 Low suspension
- R14 Mechanical speed



234 074 000    234 295 000    234 295 000    234 075 000    234 075 000    234 295 000    234 295 000    234 295 000    234 295 000    234 295 000    234 294 000

R1    R2    R3    R4    R5    R6    R7    R8    R9    R10    R11

Centrale clignotante    Démarrage    Niveau d'huile et eau    Buzzer huile    Buzzer frein à main    Éclairage    Phare cabine    Pompe fond de cuve    Phare recul    Après démarrage    Coupure pompe pulvé

234 295 000    234 295 000    234 295 000  
 R14    R13    R12  
 Vitesse mécanique    Suspension basse    Suspension haute

